



STEP 1

Detach foot from the existing telescopic leg.

STEP 2

Slide the new extension on to the tubular leg. With larger diameter facing up.

STEP 3

Fasten with supplied screw and nut.

STEP 4

Re-attach foot on to extension.

INCLUDED IN KIT:

- 1pc. - Aluminum leg extension
- 1pc. 3/8"x2"- 3/4" Hex Cap Screw
- 1pc. 3/8" Dome Nut

TOOLS REQUIRED:

- 9/16" and 5/8" wrench