



CanadaDocksTM











Where *fun* on the water *begins!*



Standing Wheel Kit for 4x8 or 8x8

Read this manual and related assembly instructions before attempting to assemble the parts enclosed to ensure that your new CanadaDocks System is assembled safely and correctly.


INCLUDED IN KIT:

WL1		2x	CB15S		2x	AX1		1x
CB35S		2x	GP1		2x	NL38		4x
WKAC1		4x	W452		2x			



PLEASE NOTE: Some of the illustrations in these instructions show the assembly of **2** axle kits for your convenience. The parts included with this kit are for **1** axle kit.

Tools Required:


9/16" SOCKET WITH RATCHET TO
SUIT OR 9/16" WRENCH



1





**HELP
RECOMMENDED**



Loosen the adjustment knobs on each of the dock legs by turning the knobs counter-clockwise (**see above image**). This will free the legs so that they can be taken off the dock. It is recommended to use one person to hold a corner of the dock upwards while another person removed the legs, one at a time.


Repeat this for any legs which will be replaced with a wheel kit.






2





Unscrew the carriage bolts connected to the feet from the four legs that you removed from **STEP 1**. The legs will be used in assembling the axle in **STEP 3**.

3




WKAC1		4x
AX1		1x
CB15S		2x
CB35S		2x
NL38		4x




Install a clamp assembly for each side of the axle (**AX1**).

4



GP1



2x

W452



2x


WL1




2x

Slide the wheel (**WL1**) and washer (**W452**) onto the assembled frame (**see above image**). Slide open the retaining wire on the hitch pin (**GP1**). Place the pin into the holes on either side of the axle (**AX1**). Close the retaining wire on the hitch pin (**GP1**). Repeat this step for all axle ends.

5




HELP
RECOMMENDED




Use one person to hold a corner of the dock upwards. Insert one end of the axle assembly at a time into the legs of the dock. *If there is more than one wheel kit to install then repeat **STEPS 1-5** for the other legs of the dock. Adjust the legs appropriately to the depth of water that you will be installing the dock in. Tighten the adjustment knobs to secure the height of the legs.

PLEASE NOTE: Take care to insert both legs of the wheel kit into the dock frame evenly. **DO NOT** try to force or insert one side of the wheel kit more then the other as this will cause binding.


6

4x8



PLEASE NOTE: Two standing dock wheels kits are shown in the image above to show a complete set on the 4x8 dock.

8x8



PLEASE NOTE: Two standing dock wheels kits are shown in the image above to show a complete set on the 8x8 dock.

NOTES:

NOTES:

Where *fun* on the water *begins!*

Please leave us a **Google review**



We'd love to hear from
you and see your photos!



Phone

705.434.0359

1.877.434.0359



Email

info@canadadocks.ca



Address

3690 Adjala-Tecumseth Tl,
Beeton ON L0G 1A0

Rev 03 20.11.24

CanadaDocks.ca

